


SETTING NETWORK TO 3G VODAFONE SMART PRIME 6




This is a guide to setting the network to 3G on the Vodafone Smart Prime 6.


The Vodafone Smart Prime 6 is a 4G enabled device. However, 4G is not available in all locations. To prevent losing connection to the network it will be best to have the mobile network set to 3G, which is more widely available.




1. Go to **Settings**. (This may be in your Apps)




2. Touch **More**.



3. Touch **Mobile Networks**.



4. Touch **Preferred Network Types**.



5. Change it to **3G/2G (Auto)**.

SETTING NETWORK TO 3G

VODAFONE SMART PRIME 6



Other features within the Vodafone Smart Prime 6 that you may wish to enable on your smartphone are:

- Setting up Email – Vodafone Smart Prime 6
- Setting your Email Signature - Vodafone Smart Prime 6
- Setting your Email Sync Period - Vodafone Smart Prime 6
- Connecting to DHB Staff WiFi – Vodafone Smart Prime 6
- Setting Out of Office responder - Vodafone Smart Prime 6
- Limiting & Restricting Background Data – Vodafone Smart Prime 6
- Turning Battery Save On - Vodafone Smart Prime 6
- Call Forwarding / Call Divert – Vodafone Smart Prime 6

For general trouble shooting see

- General Troubleshooting – Vodafone Smart Prime 6

Other important information guides for your DHB issued smartphone are:

- NRDHB Smartphone Quick Guide
- Mobile Data Usage
- Saving Battery Power

All guides can be found here: <http://pulse/OurServices/InformationTechnology/MobileServices/HowToGuides.aspx>

Please ensure that you familiarise yourself with your DHB's policies, guidelines and codes of conduct relating to mobile devices and the NRDHB and hA Acceptable Usage policy:

<http://pulse/OurServices/InformationTechnology/MobileServices/PoliciesandGuidelines.aspx>